

Remote PC Side Live View

1. Install software – IPCMultiView



2. Login in with User name: admin, and no password (blank)

A screenshot of the IPCam Login window. The window has a blue title bar with "Login" and a close button. Below the title bar, it says "Welcome use IPCamera" and "IPCam" in large blue letters. There are two input fields: "User Name:" with "admin" entered, and "Password:" which is empty. At the bottom, there are "Login" and "Cancel" buttons.

3. Click Settings




4. Click icon +



5. Input below info, click OK

Device name: Any name you like
P2P UID: Camera UID on camera
P2P Password: 8888

A screenshot of the IPC configuration window. It has a light blue background. The fields are: "Device Name:" with "Office Camera" entered and "Camera name" in red text; "P2P UID:" with "YM630C-C80D9D363DB2-46E8AA" entered and "Camera UID" in red text; "P2P Password:" with "8888" entered and "Camera password" in red text. Below these is a checkbox "Use IP address direct connection" which is unchecked. Then there are fields for "IP Address:", "Port:" (with "0" entered), "UserName:", and "Password:". At the bottom, it says "Auto make snapshot (0-Disabled), interval 0 Sec." and an "OK" button is highlighted with a red circle.

6. Click the camera to get live view

