

The second method is connecting the PC directly.

- 2.1 Download the software from website <http://ht-usb-camera.oss-cn-shenzhen.aliyuncs.com/Amcap.exe>
- 2.2 Connect USB camera to your PC and open the software ; click "Devices" → "USB2.0"; "Options" → "Preview"
- 2.3 Record the video: click "File" → "Set Capture Directory" to save capture videos; click "Capture" → "Start capture", click "Stop capture" to stop record.
- 2.4 Take the photo: click "File" → "Set Photo Directory" to save photo; click "Photo" → "File" on the photo → "save"

#### Specifications:

Item	Description
WiFi distance	10 meters
Battery usage time	2-3 hours
WiFi box size	63.7*40*16.7mm
Taking pictures and Video	Support
Power	5V
Connector	USB 2.0
WiFi box color	White ; Black
Camera	2.0 mega pixel
Resolution	640*480; 1280*720
Auxiliary light source	6LED Bright lights
Lens F / NO	2.8
Angle of view	60°
LED light switch	Adjustable
Focal distance	3CM-6CM
Format	Priority MJPG

## WiFi Endoscope Camera



### Support System:

Tablet、Android、iOS、Windows

Please read this user manual carefully before using this product

#### Features:

1. WiFi wireless connection;
2. Built in 5V 850mAh battery for power supply.
3. Support android mobile phone, iPhone, tablet PC, laptop, and all mobile phone and computer with the WIFI function.
4. It can take pictures and videos, and save in the mobile phone or computer.
5. The WiFi can be connected with four devices at the same time.
6. The WiFi box support any USB interface camera connection  
e.g. USB microscope, USB computer QQ camera, USB endoscope.

#### Download the software:

For android user scan the QR code , enter the download interface to download.

For iOS user, please use another App, scan the QR code to download, or search "guantianxia" or "HT wifi" in App store.



**App download address:**



(Android)



(iOS)



#### How to use:

##### Used on Phone:

1. After the endoscope camera is connected with WiFi box and press the power button of the WiFi box for 3 seconds until the indicator LED lightens, then find the name of endoscope device "HTendoscope\_ xx: xx: xx" on the phone, click it to connect, finally enter the password: "88888888".
2. After connection success, back to the phone desktop to find the downloaded software, open it, the icon will appear following picture, click on the connection device.




( HTwificamera )




( guantianxia )

and then you can take pictures and video.



( HTwificamera )



( guantianxia )

**Note: MJPG camera frame rate will higher than the YUV rate. So suggest you can choose to use the MJPG camera, YUV format effects has delay phenomenon.**

##### Used on Computer:

**There are two methods to use:**

**The first method is using wifi.**

- 1.1 Download the software from website <http://htwificamera.oss-cn-shenzhen.aliyuncs.com/HTcamera.exe> It must exit anti-virus software when you install, then software can be used after the successful installation.
- 1.2 After the endoscope camera is connected with the WiFi box and press the power button of the Wifi box for 3 seconds until the indicator LED lightens, and find the WiFi hot spot "HTendoscope\_ xx: xx: xx" on the computer, click it to connect, finally enter the password: "88888888"

- 1.3 Open the software  , connect the camera ,then you can take photo and video.

展开尺寸: 260\*95mm